

Thank you for buying a “*purii-air*”-chair.

We are glad you purchased a “*purii-air*” chair. Everything we know about comfort and healthy living surroundings went into the design and construction of this complete, fashionable and personal seating furniture.

Your “*purii-air*”-chair is well made, and we back it up with a limited (see details in manual) warranty. We stand behind it with a knowledgeable, dedicated Customer Care department, so should you ever have a problem, you’ll receive fast, considerate assistance.

Here at Kimmair Discovery, we invented and designed healthy seating devices in 2004. We perfected it since then, and today are a Canadian sole manufacturer of high quality, health promoting seating furniture, like your “*purii-air*”-chair.

Thanks again from all of us at “*purii-air*”,

Hong Min Kim

Founder & CEO

IMPORTANT SAFETY INSTRUCTIONS

Read *ALL* instructions before using your “purii-air”-Chair

If your purii-air chair is not used for extended period of time, please remove the battery pack. Damaged caused by defective/leaking batteries will NOT be covered by our warranty.

Adjust your purii-air chair settings according to your environment or working conditions to ensure comfortable and correct seating positions. Consult your local health/safety for recommendations if necessary.

Take frequent breaks when working in a seated working environment.

Do not use your purii-air chair out doors or in wet locations.

Do not allow purii-air chair to be used as a toy. Close attention is necessary if used by or near children.

Do not use purii-air chair for any other purpose, other than described in this user manual.

Do not use any attachments, other than those supplied or recommended by manufacture.

If any liquids have been exposed into the venting area of the purii-air chair, contact a purii-air chair authorized service department.

Keep vent area free of debris (dust, hair, lint etc.) or anything that will reduce air flow.

Do not use flammable or combustible liquids as cleaning agents.

Do not use without filter in place.

Keep purii-air chair on level surface.

In the unlikely event of continuous fan activity, contact a purii-air chair authorized service department at 1-437-800-8889 or service-warranty@kimmairdiscovery.com

Save these instructions for further use

Seating position

If you sit a lot in front of a computer, here are some tips to help your posture.

Support your back

Reduce your risk of back pain by adjusting your chair so your lower back is properly supported.

A correctly adjusted chair will reduce the strain on your back. Your “puri-air” chair is easily adjustable so you can change the height, back position and tilt.

Your knees should be slightly lower than your hips. Use a footrest, if it feels necessary.

Adjust your chair

Adjust your chair height so you can use the keyboard with your wrists and forearms straight and level with the floor. This can help prevent repetitive strain injuries.

Your elbows should be by the side of your body so your arm forms an L-shape at the elbow joint.

Rest your feet on the floor

Place your feet flat on the floor. If they're not, ask if you can have a footrest, which lets you rest your feet at a level that's comfortable.

Don't cross your legs, as this may contribute to posture-related problems.

Place your screen at eye level

Your screen should be directly in front of you. A good guide is to place the monitor about an arm's length away, with the top of the screen roughly at eye level.

To achieve this, you may need a monitor stand. If the screen is too high or too low, you'll have to bend your neck, which can be uncomfortable.

Have the keyboard straight in front of you

Place your keyboard in front of you when typing.

Leave a gap of about 4 to 6 inches (100mm-150mm) at the front of the desk to rest your wrists between bouts of typing.

Keep your arms bent in an L-shape and your elbows by your sides.

Some people like to use a wrist rest to keep their wrists straight and at the same level as the keys.

Keep your mouse close

Position and use the mouse as close to you as possible. A mouse mat with a wrist pad may help keep your wrist straight and avoid awkward bending.

If you're not using your keyboard, push it to one side to move the mouse closer to you.

Avoid screen reflection

Your screen should be as glare-free as possible. If there's glare on your screen, hold a mirror in front of the screen so you know what's causing it.

Position the monitor to avoid reflection from overhead lighting and sunlight. If necessary, pull blinds across the windows.

Adjusting the screen's brightness or contrast can make it much easier to use.

Avoid wearing bifocals

If you have bifocal spectacles, you may find them less than ideal for computer work. It's important to be able to see the screen easily without having to raise or lower your head.

If you cannot work comfortably with bifocals, you may need a different type of spectacles. Consult your optician if in doubt.

Make objects easy to reach

Position frequently used objects, such as your telephone or stapler, within easy reach. Avoid repeatedly stretching or twisting to reach things.

Avoid phone strain

If you spend a lot of time on the phone, try exchanging your handset for a headset.

Repeatedly cradling the phone between your ear and shoulder can strain the muscles in your neck.

Service & Operations

Power

Your “purii-Air” chair is battery operated. It requires eight (8) AAA-batteries, which are located in a battery-holder and inserted into the main-controller under the seat. The battery condition can be monitored via pressing the “check” toggle. The display, which is located in the front of the main-controller, will then display a number. This number represents the current charge state of the battery pack. If this value is lower than 8, it is recommended to replace the batteries, to ensure reliable operation. The system will still function, and reduced filtering efficiency may be experienced.

Battery replacement

- Remove two (2) thumb-screws from the battery cover
- Gently pull-out battery-holder, and disconnect from plug
- Install/replace “ALL” batteries (observe polarity in holder)
- Attach connector/plug and re-insert batter-holder

Filter

The active charcoal filter, which is located in the filter chamber, requires periodic replacement. The system is designed to have the filter-cartridge replaced approximately in a six (6) service interval. Depending on environmental conditions the filter may need more or less frequent changing.

Filter replacement

- Remove the fan-connector
- Remove four (4) Phillip-screws from the fan-assembly.
- Unscrew filter cartridge (counter clock-wise)
- Discard filter as per local environmental guidelines
- Install/screw in new filter cartridge (clockwise) until firmly seated
- Reinstall fan housing and re-attach connector

For “Q & A” as well as Video-tutorials, please visit the link below

<https://purii-air.com/f-a-q/>

Warranty & Service

In the unlikely event of malfunction, or your “purii-air” chair requires any service, please feel free to choose from the contact info below:

e-mail: service-warranty@kimmairdiscovery.com

Telephone: 1-437-800-8889 (consumer care)